JMEA



Fundamentals of Artificial Intelligence


Introduction to Assignment 1

www.cs.umu.se/kurser/5DV121/HT13



Follow the Path

- Create a controller that can guide the robot along a given path
 - The path is given as a sequence of coordinates





Follow the Path


- You will work with a simulated robot, in Microsoft Robotic Developer Studio 4 (MRDS)
- Create a program that can read sensors of the robot, and post commands to it
 - Communicate with the robot over HTTP






Microsoft Robotic Developer Studio 4

- Installed in all MA316 and MA326 computers
- Run it by executing StartLokarria.bat, located in c:/MRDS4/store/launchers






- Press Sticky Buttons
- Press 0
- Click and drag the joystick wheel





Connecting to MRDS

Go to http://localhost:50000/ with your web browser





Reading the position of the robot

- http://localhost:50000/lokarria/localization
- Response is given as a JSON message:

```
{"Pose": {
   "Orientation": {
      "W":0.99994486570358276,
      "X":1.2258946071597165E-06,
      "Y":2.6035801070634079E-08,
      "Z":-0.010508145205676556
   "Position": {
      "X":-0.0038332939147949219,
      "Y":0.0078214798122644424,
      "Z":0.077600784599781036
}, "Status":4, "Timestamp":904883}
```




Parsing JSON

Example in Python

```
import json
 3
 4
    msg =
5
    {"Pose": {
6
         "Orientation": {
             "W":0.99994486570358276,
8
             "X":1.2258946071597165E-06,
9
             "Y":2.6035801070634079E-08,
10
             "Z": -0.010508145205676556
11
12
         "Position": {
13
             "X": -0.0038332939147949219,
14
             "Y":0.0078214798122644424,
15
             "Z":0.077600784599781036
16
17
    }, "Status":4, "Timestamp":904883}
18
19
20
    pose = json.loads(msg)
21
    print pose['Pose']['Position']['X']
```



The position





Requesting the Pose

```
1
2
    MRDS URL = 'pettson:50000'
3
4
    import httplib
5
6
    mrds = httplib.HTTPConnection(MRDS URL)
    mrds.request('GET','/lokarria/localization')
    response = mrds.getresponse()
8
    if (response.status == 200):
10
         poseData = response.read()
         response.close()
11
         print poseData
12
13
    else:
         print 'An error occurred!'
14
```



```
2
    MRDS URL = 'pettson:50000'
    HEADERS = {"Content-type": "application/json", "Accept": "text/json"}
 3
 4
 5
     command = {
 6
         'TargetAngularSpeed':0.4,
 7
         'TargetLinearSpeed':0.2
 8
    }
 9
     import httplib, json
10
11
12
    mrds = httplib.HTTPConnection(MRDS URL)
     params = json.dumps(command)
13
    mrds.request('POST','/lokarria/differentialdrive',params,HEADERS)
14
15
     response = mrds.getresponse()
16
     status = response.status
     if response.status == 204:
17
18
         print 'Command posted.'
19
     else:
20
         print 'An error occurred!'
     response.close()
21
```



```
MRDS URL = 'pettson:50000'
    HEADERS = {"Content-type": "application/json", "Accept": "text/json"}
 4
    command = {
 5
         'TargetAngularSpeed':0.4,
         'TargetLinearSpeed':0.2
                                         How much to
 8
    }
 9
                                              turn
    import httplib
10
11
                    How fast to
    mrds = htt
                                       URL)
12
                    go forward
    params =
13
    mrds.reque
                                      ferentialdrive',params,HEADERS)
14
15
    response = mras
16
    status = response.status
    if response.status == 204:
17
                                         A positive angular
18
        print 'Command posted.'
19
    else:
                                         speed produces a left
20
        print 'An error occurred!'
                                         turn
    response.close()
21
```



```
MRDS URL = 'pettson:50000'
    HEADERS = {"Content-type": "application/json", "Accept": "text/json"}
 3
 4
 5
    command = {
         'TargetAngularSpeed':0.4,
 6
         'TargetLinearSpeed':0.2
 7
                                            NOTE! The
 8
     }
 9
                                              correct
     import httplib, json
10
                                          Content-type!
11
    mrds = httplib.HTTPConnection(MRDS Dr.
12
    params = json.dumps(command)
13
    mrds.request('POST','/lokarria/differentialdrive',params,HEADERS)
14
15
    response = mrds.getresponse()
16
     status = response.status
     if response.status == 204:
17
18
         print 'Command posted.'
19
    else:
20
         print 'An error occurred!'
     response.close()
21
```



Reading the Laser scanner

- http://pettson:50000/lokarria/laser/echoes
 - Returns 271 laser echoes (distances in m)

